








4.1 Drátový dipól

Java applet

 Output / Vstup dat	 Module	 Phase	 Dir. Pattern
 Input / Vstup dat			
Enter the radius of the wire dipole antenna:	<input type="text" value="0.002"/>		
Enter the length of the wire dipole antenna:	<input type="text" value="0.5"/>		
How many segments does the antenna have?	<input type="text" value="33"/>		
Enter the wavelength of the signal:	<input type="text" value="1"/>		
 Calculate / Vypoti		 Help	