

## 3.2 Stíněné mikropáskové vedení

### Java aplet

The screenshot shows a Java applet window with three tabs: "Input", "Longitudinal", and "Transversal". The "Input" tab is selected. Inside the "Input" tab, there is a section titled "Input Data" containing three input fields with spinners: "Frequency [GHz]" with the value 20, "Losses in substrate (% tan  $\delta$ )" with the value 0,1, and "Substrate permittivity" with the value 5. To the right of the "Input Data" section is a section titled "Type of calc" with two radio buttons: "Even modes" (which is selected) and "Odd modes". At the bottom of the applet, there are two buttons: "calculate" and "Help".