

4.2 Vzájemné impedance

Java applet

The applet interface is divided into two tabs: **Input** and **Results**. The **Input** tab is active and contains the following sections:

Input Data

Minimum value	Single value	Maximum value	Parameter
<input type="text" value="1"/>	<input type="text" value="60"/>	<input type="text" value="180"/>	length of dipole (k^l)
<input type="text" value="1"/>	<input type="text" value="60"/>	<input type="text" value="720"/>	distance of axes (k^d)
<input type="text" value="1"/>	<input type="text" value="45"/>	<input type="text" value="720"/>	movement of center points (k^h)

Type of calculation

- Single
- Change
- Change
- Change

Buttons: **calculate** and **Help**